

# Installation manual

Ordering code: MM19000VH

## **Roof 19" motorized monitor** TFT LCD; big base; polycarbonate; 11~30V DC; 400cd; 1x AV In; VGA; HDMI; contrast 800:1 + remote control



MOLPIR s.r.o., sídlo: SNP 129, 919 04 Smolenice; prevádzka: Hrachová 30, 821 05 Bratislava, Slovenská republika, tel.; +421 2 4319 1218; fax.; +421 2 431 912 20; e-mail; obchod@n IČO: 31431372, IčPD: SK2020391560; Tatrabanka Bratislava, č.ú: 2628020575/1100, register: OS Trnava, odd: Sro, vlož.: 1045/1

Date 10/06/2017

Page 1 / 5



### Power supply of the device:

Red cable: permanent plus pole

Yellow cable: Trigger plus pole of the device - optional

Black cable: permanent minus pole


Input connectors: VGA

**HDMI CINCH** 

#### **Installation of the device:**




Attach the device using six screws into prepared holes. Display has to be opened. After the installation, the device cannot be deformed. Fasten the device to flat surface, unevenness and bends are not permitted (drawing 1). If the device is mounted on the uneven surface it causes its damage (crossing), which subsequently causes the problem when opening and closing the display.








#### **Installation process:**



1. Slide the lock to the left to open the device.




2. At the same time open the LCD display in the direction of the arrow.

Date: 10/06/2017



NM\_MM19000VH\_000\_10062017\_EN






3. Attach monitor with screws. Use screws suitable for the particular holes.



Date: 10/06/2017


4. Use screws with the diameter of max. 5mm. Length of screws depends on the thickness of the wall, to which the device is attached.





5. Fixed screws should be covered by blinding plugs.

Date: 10/06/2017



6. After fixing the device, check if the device is attached properly in horizonal position.

